



## Exhibit G-2. Standard Calibration Check Procedure, Intoxilyzer Model 8000

THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104(A)  
ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST J. SANDREL 187 AGENCY LAKE NAUASU CITY PD  
 DATE 2/17/19 TIME 1455  
 INTOXILYZER SERIAL # 80-003355 LOCATION JAIL

() 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution ± 100 AC.  
 OR

Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$

- () 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"  
 () 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.  
 () 4. Air blank completed.  
 () 5. Calibration check completed. Test results 0. 101 AC.  
 () 6. Air blank completed.  
 () 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE J. Sandrel 187

DPS Form Exh G-2 (Rev 05-01)

**Historical Note**

New Exhibit G-2 made by final rulemaking at 12 A.A.R. 1916, effective 9:00 a.m., May 18, 2006 (Supp. 06-2).

INTOXILYZER 8000  
Location: JAIL  
Serial Number: 80-003355  
Core Version: 8105.48  
02/17/2019 14:55:38

-----  
Standard Lot#: 13917100A1  
Last Changed By: J. SONDROL #187  
-----

QAS: J. SONDROL #187  
LAKE HAVASU CITY PD  
-----

Operator: J. SONDROL #187  
LAKE HAVASU CITY PD  
-----

Test	g/210L	Time
Air Blank	0.000	14:56:08
0.100 Cal Check	0.101	14:56:28
Air Blank	0.000	14:56:58

Preventative Maintenance  
Performed -- Timer Reset