



POLICE DEPARTMENT
LAKE HAVASU CITY
 2360 McCULLOCH BOULEVARD NORTH
 LAKE HAVASU CITY, ARIZONA 86403-5947

To Whom It May Concern:

I hereby attest that Michael T. Maloy, Jr. is a Certified Intoxilyzer Quality Assurance Specialist for the Lake Havasu City Police Department.

I certify that the attached documentation of Standard Quality Assurance Procedures and/or Standard Calibration Check Procedure are full, true and correct copy of the original.

Michael Maloy Jr #281
 Signature

STATE OF ARIZONA)
) ss
 COUNTY OF MOHAVE)

Subscribed and sworn to before me this 28th day of May 2021
 _____ by Michael T Maloy Jr

[Signature]
 NOTARY PUBLIC

5-28-21
 DATE

Commission expires: 2-26-23



Area Code 928

- | | | | | | |
|-----------------------|----------|-----------------------------|----------|-------------------------------|----------|
| Administration | 855-4884 | Fax #'s | | Emergency | 9-1-1 |
| Business Office | 855-1171 | Administration | 680-5430 | Non-Emergency Dispatch/ | 855-4111 |
| Investigations | 855-5775 | Business Office | 680-5431 | Havasu Silent Witness | 854-TIPS |
| Patrol | 855-0515 | Investigations/Patrol | 680-5432 | | |

E-mail: police@lhcaz.gov

281

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST M. MALOY #281 AGENCY LHCPD

DATE 05-28-2021 TIME 0030

INTOXILYZER SERIAL # 80-00335b LOCATION SIGN B

- (✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (✓) 4. Air blank completed.
- (✓) 5. Calibration check completed. Test results 0. 098 AC.
- (✓) 6. Air blank completed.
- (✓) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Michael Maloy #281

INTOXIFYZER 8000
Location: CHANNEL SIGN 8
Serial Number: 80-003356
Core Version: 6105.48
05/28/2021 00:30:43

Standard Lot#: 35019100A
Last Changed By: M. MALOY JR #281

QAS: M. MALOY JR #281
LAKE HAVASU CITY PD

Operator: M. MALOY JR #281
LAKE HAVASU CITY PD

Test g/2100 Time

Air Blank 0.000 00:33:14
0.100 Cal Check 0.098 00:33:35
Air Blank 0.000 00:34:04

Preventative Maintenance
Performed -- Pimer Repair

EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST M. MALOY #281 AGENCY LHCPS

DATE 05-28-2021 TIME 0035

INTOXILYZER SERIAL # 80-003356 LOCATION SIGN 8

() 1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

() 1. Clock time check.

() 2. Date check.

OPERATIONAL TESTS

() 1. Alcohol-free subject test result 0. 000 AC.

() 2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed

() 3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed.

() 4. Standard Calibration Check standard 0. 100 AC. Result 0. 097 AC.

Instrument is operating properly and accurately. YES NO

COMMENTS

SIGNATURE Michael Maloy #281

281

INTOXILYZER 8000
Location: CHANNEL SIGN 8
Serial Number: 80-003356
Core Version: 8105.48
05/28/2021

00:35:09

Standard Lot#: 35019100A1
Last Changed By: M. MALOY JR #281

QAS: M. MALOY JR #281
LAKE HAVASU CITY PD

Operator: M. MALOY JR #281
LAKE HAVASU CITY PD

Subject: SQAP,TEST
DOB: 01/01/2000
Sex: M Weight: 200

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	00:36:05
Diagnostic Test	Pass	00:36:40
Air Blank	0.000	00:37:07
0.100 Cal Check	0.098	00:37:28
Air Blank	0.000	00:37:58
Subject Test	0.000	00:38:20
Air Blank	ABT*	00:38:27
Air Blank	IPS**	00:38:35

*Sequence Aborted

**Improper Sample

Not a Successfully Completed Test Sequence

281

INTOXILYZER 8000
Location: CHANNEL SIGN 8
Serial Number: 80-003356
Core Version: 8105.48
05/28/2021

00:39:14

Standard Lot#: 35019100A1
Last Changed By: M. MALOY JR #281

QAS: M. MALOY JR #281
LAKE HAVASU CITY PD

Operator: M. MALOY JR #281
LAKE HAVASU CITY PD

Subject: SQAP,TEST
DOB: 01/01/2000
Sex: M Weight: 200

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	00:40:09
Diagnostic Test	Pass	00:40:44
Air Blank	0.000	00:41:12
0.100 Cal Check	0.099	00:41:33
Air Blank	0.000	00:42:02
Subject Test	0.000*	00:45:10
Air Blank	0.000	00:45:37
Air Blank	0.000	00:46:04
Subject Test	XXX**	00:47:02
Air Blank	RFI***	00:47:15

*Deficient Sample
**Invalid Sample
 Begin new deprivation period
***RFI Detect

Not a Successfully Completed Test Sequence

281

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST M. MALOY #281 AGENCY LHCPS

DATE 05-28-2021 TIME 0048

INTOXILYZER SERIAL # 80-00335b LOCATION SIGN B

- () 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- () 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- () 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- () 4. Air blank completed.
- () 5. Calibration check completed. Test results 0. 097 AC.
- () 6. Air blank completed.
- () 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Michael Maloy #281

281

INTOXILYZER 8000
Location: CHANNEL SIGN 8
Serial Number: 80 003356
Core Version: 8105.48
05/28/2021 00:48:02

Standard Lot#: 35019100A1
Last Changed By: M. MALOY JR #281

QAS: M. MALOY JR #281
LAKE HAVASU CITY PD

Operator: M. MALOY JR #281
LAKE HAVASU CITY PD

Test	g/210L	Time
Air Blank	0.000	00:48:32
0.100 Cal Check	0.097	00:48:53
Air Blank	0.000	00:49:23

Preventative Maintenance
Performed -- Timer Reset