



POLICE DEPARTMENT  
**LAKE HAVASU CITY**

2360 McCULLOCH BOULEVARD NORTH  
LAKE HAVASU CITY, ARIZONA 86403-5947

To Whom It May Concern:

I hereby attest that Michael T. Maloy, Jr. is a Certified Intoxilyzer Quality Assurance Specialist for the Lake Havasu City Police Department.

I certify that the attached documentation of Standard Quality Assurance Procedures and/or Standard Calibration Check Procedure are full, true and correct copy of the original.

Michael Maloy Jr #281  
Signature

STATE OF ARIZONA        )  
  ) ss  
COUNTY OF MOHAVE    )

Subscribed and sworn to before me this 28th day of JANUARY.

2022 by MICHAEL MALOY

Shawna Mcknight  
NOTARY PUBLIC

JANUARY 28th 2022  
DATE

Commission expires: MAY 4, 2025



Area Code 928

Administration ..... 855-4884  
Business Office ..... 855-1171  
Investigations ..... 855-5775  
Patrol ..... 855-0515

Fax #'s  
Administration ..... 680-5430  
Business Office ..... 680-5431  
Investigations/Patrol ..... 680-5432

Emergency ..... 9-1-1  
Non-Emergency Dispatch/ ..... 855-4111  
Havasu Silent Witness ..... 854-TIPS

E-mail: police@lhcaz.gov

281

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST M. MAWY #281 AGENCY LNLPD  
DATE 01-28-2022 TIME 2242  
INTOXILYZER SERIAL # 80-003356 LOCATION SIBN 8

- (  ) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.  
OR  
Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C
- (  ) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (  ) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (  ) 4. Air blank completed.
- (  ) 5. Calibration check completed. Test results 0. 098 AC.
- (  ) 6. Air blank completed.
- (  ) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Michael Mawzy #281

281

INTOXILYZER 8000  
Location: CHANNEL SIGN 8  
Serial Number: 80-003356  
Core Version: 8105.48  
01/28/2022 22:42:30

-----  
Standard Lot#: 35019100A1  
Last Changed By: M. MALOY JR #281  
-----

QAS: M. MALOY JR #281  
LAKE HAVASU CITY PD  
-----

Operator: M. MALOY JR #281  
LAKE HAVASU CITY PD  
-----

Test	g/210L	Time
Air Blank	0.000	22:43:11
0.100 Cal Check	0.098	22:43:32
Air Blank	0.000	22:44:01

Preventative Maintenance  
Performed -- Timer Reset

EXHIBIT G-4  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST M. MALOY #281 AGENCY LHCPD

DATE 01-28-2022 TIME 2246

INTOXILYZER SERIAL # 80-003356 LOCATION SIGN 8

(  ) 1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- (  ) 1. Clock time check.
- (  ) 2. Date check.

OPERATIONAL TESTS

- (  ) 1. Alcohol-free subject test result 0. 000 AC.
- (  ) 2. Error recognition logic system functioning.  
Not a Successfully Completed Test Sequence printed
- (  ) 3. Proper sample recognition system.  
Not a Successfully Completed Test Sequence printed  
Deficient sample printed.
- (  ) 4. Standard Calibration Check standard 0. 100 AC. Result 0. 098 AC.

Instrument is operating properly and accurately. YES  NO

COMMENTS

INSTRUMENT TAKEN OUT OF SERVICE TO BE  
REPLACED WITH INTDX 9000.

SIGNATURE Michael Maloy Jr #281

201

INTOXILYZER 8000

Location: CHANNEL SIGN 8

Serial Number: 80-003356

Core Version: 8105.48

01/28/2022

22:46:40

---

Standard Lot#: 35019100A1

Last Changed By: M. MALOY JR #281

---

QAS: M. MALOY JR #281

LAKE HAVASU CITY PD

---

Operator: M. MALOY JR #281

LAKE HAVASU CITY PD

---

Subject: SQAP,TEST

DOB: 01/01/2000

Sex: M Weight: 200

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	0.000	22:47:27
Diagnostic Test	Pass	22:48:02
Air Blank	0.000	22:48:30
0.100 Cal Check	0.099	22:48:50
Air Blank	0.000	22:49:20
Subject Test	0.000	22:49:51
Air Blank	ABT*	22:49:59
Air Blank	IPS**	22:50:08

\*Sequence Aborted

\*\*Improper Sample

**Not a Successfully Completed Test Sequence**

281

INTOXILYZER 8000  
Location: CHANNEL SIGN 8  
Serial Number: 80-003356  
Core Version: 8105.48  
01/28/2022 22:50:36

---

Standard Lot#: 35019100A1  
Last Changed By: M. MALOY JR #281

---

QAS: M. MALOY JR #281  
LAKE HAVASU CITY PD

---

Operator: M. MALOY JR #281  
LAKE HAVASU CITY PD

---

Subject: SQAP,TEST  
DOB: 01/01/2000  
Sex: M Weight: 200

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	0.000	22:51:25
Diagnostic Test	Pass	22:52:00
Air Blank	0.000	22:52:27
0.100 Cal Check	0.099	22:52:48
Air Blank	0.000	22:53:18
Subject Test	0.000*	22:56:25
Air Blank	0.000	22:56:52
Air Blank	0.000	22:57:20
Subject Test	XXX**	22:57:51
Air Blank	RFI***	22:58:08

\*Deficient Sample  
\*\*Invalid Sample  
    Begin new deprivation period  
\*\*\*RFI Detect

**Not a Successfully Completed Test Sequence**

281

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST M. MALOY #281 AGENCY LHCPD  
DATE 01-28-2022 TIME 2259  
INTOXILYZER SERIAL # 80-003356 LOCATION SIGN 8

- () 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.  
OR  
Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C
- () 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- () 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- () 4. Air blank completed.
- () 5. Calibration check completed. Test results 0. 098 AC.
- () 6. Air blank completed.
- () 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Michael Maloy #281

281

INTOXILYZER 8000  
Location: CHANNEL SIGN 8  
Serial Number: 80-003356  
Core Version: 8105.48  
01/28/2022 22:59:00

-----  
Standard Lot#: 35019100A1  
Last Changed By: M. MALOY JR #281  
-----

QAS: M. MALOY JR #281  
LAKE HAVASU CITY PD  
-----

Operator: M. MALOY JR #281  
LAKE HAVASU CITY PD  
-----

Test	g/210L	Time
Air Blank	0.000	22:59:29
0.100 Cal Check	0.098	22:59:50
Air Blank	0.000	23:00:20

Preventative Maintenance  
Performed -- Timer Reset