

To Whom It May Concern:

I hereby attest that Josh Sondrol is a Certified Intoxilyzer Quality Assurance Specialist for the Lake Havasu City Police Department.

I certify that the attached documentation of Standard Quality Assurance Procedures and/or Standard Calibration Check Procedure are full, true and correct copy of the original.

Commission expires:



Administration	855-4884
Business Office	855-1171
Investigations	855-5775
Patrol	855-0515

Fax #'s	
Administration	680-5430
Business Office	680-5431
Investigations/Patrol	680-5432

Area Code 928

Emergency	9-1-1
Non-Emergency Dispatch/	. 855-4111
Havasu Silent Witness	854-TIPS

E-mail: police@lhcaz.gov

EXHIBIT G-2 THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST J. SUNDROL 187 AGENCY LNC PD
DATE 5/22/17 TIME 2320
INTOXILYZER SERIAL# 80-003356 LOCATION TAIL
() I. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution . !()()AC
Pour a standard alcohol concentration solutionAC, into a clean dry simulator and assemble the
simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C± 0.2°C
() 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
(*\forall 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
() 4. Air blank completed.
(5 4. All brain completed. Test results 0. 096 AC.
6. Air blank completed.
() 6. Air blank completed. () 7. Remove printed record. Attach the record to the completed checklist.
SIGNATURE CLOVELLET
DPS Form Exh G-2 (Rev 05-01)

95187

INTOXILYZER 8000 Location: MAIN JAIL Serial Number: 80-003356 Core Version: 8105.48

05/22/2017 23:20:05

Standard Lot#: 2231510CA:

Last Changed By: J. SONDROL #187

QAS: J. SONDROL #187 LAKE HAVASU CITY PD

-- ----- ----- -----

Operator: J. SONDROL #187

LAKE HAVASU CITY PD

Test	g/210L	Time
	·	· · ·
Air Blank	0.000	23:20:36

 0.100 Cal Check
 0.096
 23:20:57

 Air Blank
 0.000
 23:21:26

Preventative Maintenance Porformed -- Timer Reset

EXHIBIT G-4 THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST J SUL DRIZ 187	AGENCY CNC PD
DATE 5/22/17	TIME 2337
INTOXILYZER SERIAL# 80-003356	
(🌱 1. Display Reads "PUSH BUTTON TO START"	
DIAGNOSTIC TESTS () 1. Clock time check. () 2. Date check.	
Instrument is operating properly and accurately. YES	cc printed
COMMENTS	
-	
SIGNATURE Storell 187	
)PS Form Exh G-4 (Rev 05-01)	
- '(
•	

INTOXILYZER 8000 Location: MAIN JAIL

Serial Number: 80-003356 Core Version: 8105.48

05/22/2017

23:38:38

Standard Lot#: 22315100A1 Last Changed By: J. SONDROL	#187
QAS: J. SONDROL LAKE HAVASU CITY PD	#187
Operator: J. SONDROL	#187

Subject: SQAP, TEST DOB: 01/01/1950

Sex: M

Weight: 123

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	23:39:33
Diagnostic Test	Pass	23:40:08
Air Blank	0.000	23:40:36
0.100 Cal Check	0.096	23:40:57
Air Blank	0.000	23:41:26
Subject Test	0.000	23:41:50
Air Blank	ABT*	23:41:57
Air Blank	IPS**	23:42:06

^{*}Sequence Aborted

Not a Successfully Completed Test Sequence

^{**}Improper Sample

INTOXILYZER 8000 Location: MAIN JAIL

Serial Number: 80-003356 Core Version: 8105.48

05/22/2017

23:42:56

Standard Lot#: 22315100A1	
Last Changed By: J. SONDROL	#187
QAS: J. SONDROL, LAKE HAVASU CITY PD	#187
Operator: J. SONDROL LAKE HAVASU CITY PD	#187

Subject: SQAP, TEST DOB: 01/01/1950

Sex: M

Weight: 123

15 Minute Deprivation Period? Yes

Test	- /210+	
	g/210L	Time
Air Blank	0.000	23:43:42
Diagnostic Test	Pass	23:44:17
Air Blank	0.000	23:44:45
0.100 Cal Check	0.096	23:45:06
Air Blank	0.000	23:45:35
Subject Test	0.479*	23:48:42
Air Blank	0.000	23:49:16
Air Blank	0.000	23:49:44
Subject Test	XXX**	23:50:11
Air Blank	RFI***	23:50:25

^{*}Deficient Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

^{**}Invalid Sample

^{***}RFI Detect

EXHIBIT G-2 THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST J SOUDRER 187	AGENCY LNC PD
DATE 5/22/17	TIME <u>2351</u>
INTOXILYZER SERIAL# <u>80-003356</u>	LOCATION JAIL
(1) 1. Ensure that gas tank is attached to instrument and co	
Pour a standard alcohol concentration solution	AC, into a clean dry simulator and assemble the
simulator. Ensure that a tight seal has been made. T 0.2°C	um on the simulator and allow temperature to reach 34°C \pm
(1) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO	START"
 Intoxilyzer 8000 display reads "PUSH BUTTON TO Go to the "Control Testing Menu". Select "D" for dr made press ENTER. 	
() 4. Air blank completed.	
5. Calibration check completed. Test results 0. 7	5 AC.
6. Air blank completed.	
4. Air blank completed. 5. Calibration check completed. Test results 0. 7 6. Air blank completed. 7. Remove printed record. Attach the record to the completed.	pleted checklist.
GIGNATURE G Sord 187	
PS Form Exh G-2 (Rev 05-01)	

INTOXILYZER 8000 Location: MAIN JAIL Serial Number: 80-003356 Core Version: 8105.48

05/22/2017 23:51:41

Standard Lot#: 22315100A1

Last Changed By: J. SONDROL #187

QAS: J. SONDROL #187 LAKE HAVASU CITY PD

Operator: J. SONDROL #187

LAKE HAVASU CITY PD

Test	g/210L	Time
Air Blank	0.000	23:52:10
0.100 Cal Check	0.095	23:52:31
Air Blank	0.000	23:53:01

Preventative Maintenance Performed -- Timer Reset