



POLICE DEPARTMENT  
**LAKE HAVASU CITY**  
2360 McCULLOCH BOULEVARD NORTH  
LAKE HAVASU CITY, ARIZONA 86403-5947

To Whom It May Concern:

I hereby attest that Michael T. Maloy, Jr. is a Certified Intoxilyzer Quality Assurance Specialist for the Lake Havasu City Police Department.

I certify that the attached documentation of Standard Quality Assurance Procedures and/or Standard Calibration Check Procedure are full, true and correct copy of the original.

Michael Maloy Jr #281  
Signature

STATE OF ARIZONA            )  
  ) ss  
COUNTY OF MOHAVE        )

Subscribed and sworn to before me this 29<sup>th</sup> day of January.

2021 by Michael T. Maloy Jr.

[Signature]  
NOTARY PUBLIC

1-29-21  
DATE

Commission expires: 2-26-23



Area Code 928

- |                                |                                      |  |
|--------------------------------|--------------------------------------|--|
| Administration ..... 855-4884  | Fax #'s                              | Emergency ..... 9-1-1                  |
| Business Office ..... 855-1171 | Administration ..... 680-5430        | Non-Emergency Dispatch/ ..... 855-4111 |
| Investigations ..... 855-5775  | Business Office ..... 680-5431       | Havasu Silent Witness ..... 854-TIPS   |
| Patrol ..... 855-0515          | Investigations/Patrol ..... 680-5432 |  |

E-mail: police@lhcaz.gov

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST M. MALOY #281 AGENCY LHCPO

DATE 01-29-2021 TIME 10:22

INTOXILYZER SERIAL # 80-003356 LOCATION SIBN 8

- (  ) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.  
OR  
Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C
- (  ) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (  ) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (  ) 4. Air blank completed.
- (  ) 5. Calibration check completed. Test results 0. 099 AC.
- (  ) 6. Air blank completed.
- (  ) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Michael Maloy #281

281

INTOXILYZER 8000  
Location: CHANNEL SIGN 8  
Serial Number: 80-003356  
Core Version: 8105.48  
01/29/2021 10:22:38

-----  
Standard Lot#: 35019100A1  
Last Changed By: M. MALOY JR #281  
-----

QAS: M. MALOY JR #281  
LAKE HAVASU CITY PD  
-----

Operator: M. MALOY JR #281  
LAKE HAVASU CITY PD  
-----

Test	g/210L	Time
Air Blank	0.000	10:23:34
0.100 Cal Check	0.099	10:23:55
Air Blank	0.000	10:24:25

Preventative Maintenance  
Performed -- Timer Reset

EXHIBIT G-4  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST M. MALOY #281 AGENCY LINCPO

DATE 01-29-2021 TIME 10:25

INTOXILYZER SERIAL # 80-003356 LOCATION SIGN B

(  ) 1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- (  ) 1. Clock time check.
- (  ) 2. Date check.

OPERATIONAL TESTS

- (  ) 1. Alcohol-free subject test result 0. 000 AC.
- (  ) 2. Error recognition logic system functioning.  
Not a Successfully Completed Test Sequence printed
- (  ) 3. Proper sample recognition system.  
Not a Successfully Completed Test Sequence printed  
Deficient sample printed.
- (  ) 4. Standard Calibration Check standard 0. 100 AC. Result 0. 098 AC.

Instrument is operating properly and accurately. YES  NO

COMMENTS

TAKEN OUT OF SERVICE FOR SCHEDULED  
ANNUAL PREVENTATIVE MAINTENANCE

---



---



---

SIGNATURE Michael Maloy #281

281

INTOXILYZER 8000  
Location: CHANNEL SIGN 8  
Serial Number: 80-003356  
Core Version: 8105.48  
01/29/2021

10:25:21

---

Standard Lot#: 35019100A1  
Last Changed By: M. MALOY JR #281

---

QAS: M. MALOY JR #281  
LAKE HAVASU CITY PD

---

Operator: M. MALOY JR #281  
LAKE HAVASU CITY PD

---

Subject: SQAP,TEST  
DOB: 01/01/2000  
Sex: M Weight: 200

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	0.000	10:26:22
Diagnostic Test	Pass	10:26:57
Air Blank	0.000	10:27:25
0.100 Cal Check	0.098	10:27:46
Air Blank	0.000	10:28:16
Subject Test	0.000	10:28:34
Air Blank	ABT*	10:28:40
Air Blank	IPS**	10:28:48

\*Sequence Aborted  
\*\*Improper Sample

**Not a Successfully Completed Test Sequence**

281

INTOXILYZER 8000  
Location: CHANNEL SIGN 8  
Serial Number: 80-003356  
Core Version: 8105.48  
01/29/2021

10:29:19

---

Standard Lot#: 35019100A1  
Last Changed By: M. MALOY JR #281

---

QAS: M. MALOY JR #281  
LAKE HAVASU CITY PD

---

Operator: M. MALOY JR #281  
LAKE HAVASU CITY PD

---

Subject: SQAP,TEST  
DOB: 01/01/2000  
Sex: M Weight: 200

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	0.000	10:30:09
Diagnostic Test	Pass	10:30:44
Air Blank	0.000	10:31:12
0.100 Cal Check	0.099	10:31:33
Air Blank	0.000	10:32:02
Subject Test	0.000*	10:35:10
Air Blank	0.000	10:35:37
Air Blank	0.000	10:36:05
Subject Test	XXX**	10:36:20
Air Blank	RFI***	10:36:37

\*Deficient Sample  
\*\*Invalid Sample  
    Begin new deprivation period  
\*\*\*RFI Detect

**Not a Successfully Completed Test Sequence**

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST M. MALOY #281 AGENCY LNCPD  
DATE 01-29-2021 TIME 10:37  
INTOXILYZER SERIAL # 80-003350 LOCATION SIGN B

- (  ) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.  
OR  
Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C
- (  ) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (  ) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (  ) 4. Air blank completed.
- (  ) 5. Calibration check completed. Test results 0. 098 AC.
- (  ) 6. Air blank completed.
- (  ) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Michael Maloy #281

281

INTOXILYZER 8000  
Location: CHANNEL SIGN 8  
Serial Number: 80-003356  
Core Version: 8105.48  
01/29/2021 10:37:22

-----  
Standard Lot#: 35019100A1  
Last Changed By: M. MALOY JR #281  
-----

QAS: M. MALOY JR #281  
LAKE HAVASU CITY PD  
-----

Operator: M. MALOY JR #281  
LAKE HAVASU CITY PD  
-----

Test	g/210L	Time
Air Blank	0.000	10:37:56
0.100 Cal Check	0.098	10:38:17
Air Blank	0.000	10:38:46

Preventative Maintenance  
Performed -- Timer Reset