



EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST J SANDOZ 187 AGENCY LNC PD  
DATE 2/20/17 TIME 1133  
INTOXILYZER SERIAL # 80-003356 LOCATION MARIN JAIL

- (✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.  
OR  
Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (✓) 4. Air blank completed.
- (✓) 5. Calibration check completed. Test results 0.095 AC.
- (✓) 6. Air blank completed.
- (✓) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE J Sandoz 187

08187

INTOXILYZER 8000  
Location: MAIN JAIL  
Serial Number: 80-003356  
Core Version: 8105.48  
02/20/2017 11:33:47

-----  
Standard Lot#: 2231510CA1  
Last Changed By: J. SONDRON #187  
-----

QAS: J. SONDRON #187  
LAKE HAVASU CITY PD  
-----

Operator: J. SONDRON #187  
LAKE HAVASU CITY PD  
-----

Test	g/210L	Time
Air Blank	0.000	11:34:17
0.100 Cal Check	0.095	11:34:37
Air Blank	0.000	11:35:07

Preventative Maintenance  
Performed -- Timer Reset

EXHIBIT G-4  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST J SANDRAC 187 AGENCY LHC PD  
DATE 2/20/17 TIME 1157  
INTOXILYZER SERIAL # 80-003356 LOCATION MARICOPA JAIL

1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

1. Clock time check.  
 2. Date check.

OPERATIONAL TESTS

1. Alcohol-free subject test result 0. 000 AC.  
 2. Error recognition logic system functioning.  
Not a Successfully Completed Test Sequence printed  
 3. Proper sample recognition system.  
Not a Successfully Completed Test Sequence printed  
Deficient sample printed.  
 4. Standard Calibration Check standard 0. 100 AC. Result 0. 095 AC.

Instrument is operating properly and accurately. YES  NO

COMMENTS

SIGNATURE [Signature]

INTOXILYZER 8000  
Location: MAIN JAIL  
Serial Number: 80-003356  
Core Version: 8105.48  
02/20/2017

11:37:04

---

Standard Lot#: 22315100A1  
Last Changed By: J. SONDRÖL #187

---

QAS: J. SONDRÖL #187  
LAKE HAVASU CITY PD

---

Operator: J. SONDRÖL #187  
LAKE HAVASU CITY PD

---

Subject: SQAP, TEST  
DOB: 01/01/1950  
Sex: M Weight: 123

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	0.000	11:38:32
Diagnostic Test	Pass	11:39:07
Air Blank	0.000	11:39:34
0.100 Cal Check	0.094	11:39:55
Air Blank	0.000	11:40:24
Subject Test	0.000	11:40:46
Air Blank	ABT*	11:40:52
Air Blank	IPS**	11:41:00

\*Sequence Aborted  
\*\*Improper Sample

Not a Successfully Completed Test Sequence

INTOXILYZER 8000  
Location: MAIN JAIL  
Serial Number: 80-003356  
Core Version: 8105.48  
02/20/2017

11:41:47

---

Standard Lot#: 22315100A1  
Last Changed By: J. SONDROL #187

---

QAS: J. SONDROL #187  
LAKE HAVASU CITY PD

---

Operator: J. SONDROL #187  
LAKE HAVASU CITY PD

---

Subject: SQAP,TEST  
DOB: 01/01/1950  
Sex: M Weight: 123

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	0.000	11:42:33
Diagnostic Test	Pass	11:43:08
Air Blank	0.000	11:43:36
0.100 Cal Check	0.095	11:43:56
Air Blank	0.000	11:44:26
Subject Test	0.130*	11:47:33
Air Blank	0.000	11:48:10
Air Blank	0.000	11:48:37
Subject Test	XXX**	11:49:00
Air Blank	RFI***	11:49:08

\*Deficient Sample

\*\*Invalid Sample

Begin new deprivation period

\*\*\*RFI Detect

**Not a Successfully Completed Test Sequence**

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST J SONDROL 187 AGENCY LNC PD  
DATE 2/20/17 TIME 1150  
INTOXILYZER SERIAL # 80-003356 LOCATION MAIN JAIL

- () 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution . 100 AC.  
OR  
Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- () 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- () 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- () 4. Air blank completed.
- () 5. Calibration check completed. Test results 0. 094 AC.
- () 6. Air blank completed.
- () 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE J Sondrol 187

4/187

INTOXILYZER 8000  
Location: MAIN JAIL  
Serial Number: 80-003356  
Core Version: 8105.48  
02/20/2017 11:50:58

-----  
Standard Lot#: 22315100A1  
Last Changed By: J. SONDRÖL #187  
-----

QAS: J. SONDRÖL #187  
LAKE HAVASU CITY PD  
-----

Operator: J. SONDRÖL #187  
LAKE HAVASU CITY PD  
-----

Test	g/210L	Time
Air Blank	0.000	11:51:27
0.100 Cal Check	0.094	11:51:47
Air Blank	0.000	11:52:17

Preventative Maintenance  
Performed -- Timer Reset